

KIT CONTENTS

NO.	DESCRIPTION	QTY
1	Intake Pipe	1
2	63mm Silicone Hose	1
3	Heatshield	1
4	Clamps	2
5	Air Filter	1

Please Check the Contents of this box immediately.

Report any defective or missing parts to us or our dealer that you purchased this product form. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the our dealer or local modified car factory. Installing does require some mechanical skills. A qualified mechanic is always recommended.

※Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot.

MST Performance Auto Parts offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

*All installation of parts must be performed by a trained professional.





Figure 1. Project overview.
原廠引擎圖



Figure 2. Loosen the clamps to unclip and remove the intake hose from the air box lid
鬆開夾子以鬆開並從空氣箱蓋上取下進氣軟管



Figure 3. Unclip and remove the electrical plug from the hose
從軟管上鬆開並取下電插頭



Figure 4 . Remove the bolts from the air box lid and put them aside for install later.
從空氣箱蓋上拆下螺栓，並將其放在一邊以備後用



Figure 5. Remove the air box lid from the vehicle.從車輛上拆下空氣箱蓋



Figure 6 . Install the MST heatshield lining up the grommets with the holes on the base
安裝 MST 隔熱罩，使索環與底座上的孔對齊



Figure 7. Take the bolts that removed from step 4.
取出步驟 4 中拆下的螺栓



Figure 8. Secure the heat shield with bolts.
用螺栓固定隔熱罩



Figure 9. Install the aluminum piece to the heat shield.

將鋁片安裝到隔熱罩上



Figure 10. Install the silicone hose.

安裝矽膠軟管



Figure 11. Slide two clamps to each side of the silicone hose, joint the silicone hose and aluminum piece. Tighten the clamps later.

將兩個夾子滑動到矽膠軟管的每一側，連接矽膠軟管和鋁片。稍後擰緊夾子



Figure 12. Refit the electrical plug that has been removed from step 3.

重新安裝從步驟 3 中拔下的電源插頭



Figure 13. Slide the clamp to MST air filter then insert to the heat shield.

將夾子滑到 MST 空氣過濾器上，然後插入隔熱罩



Figure 14. Tighten the clamps (see figure 11) to secure. (Do not overtighten)

擰緊夾具（見圖 11）以固定。（不要擰得太緊）



Figure 15. Tighten the clamp to secure the air filter. (Do not overtighten)

擰緊夾子以固定空氣過濾器。（不要擰得太緊）



Figure 16: Congratulations! It's all set. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.

恭喜！一切就緒。定期檢查進氣口的對齊情況，正常磨損會導致螺母和螺栓鬆動。