



Installation Instructions For

2015+ Audi S4/S5 B9 2.9T

KIT CONTENTS

NO.	DESCRIPTION	QTY	
1	Silicone Tube	1	Please Check the Contents of this box immediately. Report any defective or missing parts to us or our dealer that you purchased this product form. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the our dealer or local modified car factory. Installing does require some mechanical skills. A qualified mechanic is always recommended. ※Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot. MST Performance Auto Parts offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.
2	Heat Shield	1	
3	Heat Shield Cover	1	
4	Air Filter 115/89mm	1	
5	M4 Bolt 10mm kit	3	
6	89-83 ALU Tube	1	
7	M6 Bolt	2	
8	M6 Washer	2	
9	M6 Spring Washer	2	
10	Heat Shield Mount	2	
			*All installation of parts must be performed by a trained professional.





Figure 1: Loosen the hose clamp and remove the air box.
鬆開軟管夾並拆下原廠集氣箱。



Figure 4: Install the heat shield.安裝隔熱罩



Figure 2: Remove the rubber from the stock air box and install the ALU mount on rubber.
從原廠集氣箱中取出橡膠並將 ALU 安裝座安裝在橡膠上



Figure 5: Secure with bolt.用螺栓固定



Figure 3: Install the ALU mount and rubber.
安裝 ALU 安裝座和橡膠



Figure 6: Install the MST silicone hose.
安裝MST矽膠軟管



Figure 7: Install the MST tube.安裝MST鋁管



Figure 8: Install the air filter.安裝空氣過濾器



Figure 9: Install the heat shield cover and secure with bolt.安裝隔熱罩並用螺栓固定



Figure 10: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.

恭喜！您剛剛完成了此進氣系統的安裝。定期檢查進氣口的對準情況，正常磨損會導致螺帽和螺栓鬆動