



Installation Instructions For

2015+ Mercedes Benz C300 (M274)

KIT CONTENTS

NO.	DESCRIPTION	QTY	
1	Intake Tube	1	Please Check the Contacts of this box immediately. Report any defective or missing parts to us or our dealer that you purchased this product form. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the our dealer or local modified car factory. Installing does require some mechanical skills. A qualified mechanic is always recommended. ※Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot. MST Performance Auto Parts offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.
2	Heat Shield	1	
3	Heat Shield Cover	1	
4	Air Filter	1	
5	M4 Bolt 8mm	10	
6	M4 Spring Washer	10	
7	M4 Washer	10	
8	M6 Bolt	3	
9	M6 Washer	3	
10	M6 Spring Washer	3	
11	Bracket	2	
12	Bracket Mount	3	

*All installation of parts must be performed by a trained professional.



※ Turn off the ignition and disconnect the negative battery cable.

NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicle's anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code.



Figure 1: Stock factory airbox.
原廠引擎室



Figure 4: Unclip the sensor.
鬆開感應器



Figure 2: Remove the air ducts.
拆下空氣管道



Figure 5: Loosen the bolt at the factory airbox.
鬆開原廠氣箱處的螺栓



Figure 3: Loosen hose clamp at the factory tube.
鬆開原廠管上的軟管夾



Figure 6: Remove the factory airbox cover.
拆下原廠氣箱蓋



Figure 7: Remove the factory airbox.
拆下原廠氣箱



Figure 9: Install the mount on the breaket.
將安裝座安裝到斷路器上



Figure 8: Remove the sensors at the factory airbox carefully.
小心地拆下原廠氣箱中的感應器



Figure 11: Install the breaket on the heat shield.
將斷路器安裝在隔熱罩上



Figure 9: Put into the filter rubber and feel it tight.
放入過濾膠中，感覺是緊的



Figure 12: Install the mount on the breaket.
將安裝座安裝到斷路器上



Figure 13: Install the breaket on the heat shield.
將斷路器安裝在隔熱罩上



Figure 16: Install the heat shield.
安裝隔熱罩



Figure 14: Remove the rubber at the factory airbox.
去除原廠氣箱中的橡膠



Figure 17: Install the intake tube.
安裝進氣管



Figure 15: Install the rubber on the heat shield breaket.
將橡膠安裝到隔熱罩支架上



Figure 19: Install the air filter.
安裝空氣濾芯



Figure 20: Connect the mass air sensor. Make sure the wire is smooth and has "No twist"
 連接空氣品質感測器



Figure 21: Install the air ducts.
 安裝空氣管道



Figure 22: Install the heat shield cover and secure with bolt. 安裝隔熱罩並用螺栓固定
 M4 Bolt 8mm x6



Figure 23: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.

恭喜！您剛剛完成了此進氣系統的安裝。定期檢查進氣口的對準情況，正常磨損會導致螺帽和螺栓鬆脫。