



Installation Instructions For

2021+ VAG GOLF R MK8/TIGUAN R EA888 EVO4

KIT CONTENTS

NO.	DESCRIPTION	QTY
1	Intake Tube 100mm	1
2	Heat Shield	1
3	Heat Shield Cover	1
4	M4 Bolt 10mm Kit	5
5	Silicone Inlet Hose	1
6	Air Filter 115/100mm	1
7	3 3/4 Clamp	1
8	4 1/2 Clamp	1
9	2 Clamp	1

Please Check the Contents of this box immediately.

Report any defective or missing parts to us or our dealer that you purchased this product form.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the our dealer or local modified car factory.

Installing does require some mechanical skills. A qualified mechanic is always recommended.

※Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot.

MST Performance Auto Parts offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

*All installation of parts must be performed by a trained professional.





Figure 1: Stock air box.



Figure 4: Remove the stock PCV and inlet tube



Figure 2: Loosen the clamp.



Figure 5: Remove the stock PCV hose.



Figure 3: Loosen the clamp.



Figure 6: Remove the stock air box.



Figure 7: Install the MST silicone hose.



Figure 10: Install the MST air filter.



Figure 8: Install the MST heat shield.



Figure 11: Install the heat shield cover.



Figure 9: Install the MST intake tube.



Figure 12: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.