SuperCircuit

Thank you for the purchase. Please follow the below pictures as a guide to install the SUPERCIRCUIT Front Strut Bar to the Proton X70.

First, remove the original engine covers at the engine bay.

Please follow the sequence shown in the pictures below to unplug the plastic clips and remove each cover carefully at the engine bay.

Step 1

①

💡 Keep the original clips safely for reinstallation purpose.

Step 2

②

Step 3

③

Step 4

④

SuperCircuit

The SUPERCIRCUIT Front Strut Bar is designed for direct bolt-on application, no cut or mod is required. Please utilize the original bolts to install the SUPERCIRCUIT Front Strut Bar as shown in the picture below.

To reinstall the original engine covers after the SUPERCIRCUIT Front Strut Bar is installed, repeat Step 1-4 in reverse sequence.

Should you need any further assistance during the installation, please contact SUPERCIRCUIT BARS, Tel: +6 03 5632 2855 or send us a message on Facebook:

https://www.facebook.com/SuperCircuitBarsMalaysia