



1

Place base on a flat, level surface only.

Push 4 rubber feet onto base as shown.

Lower main section of rack onto base.

Grub screws face back.

Tighten grub screws.

2

Insert top section into tubes of main section.

Insert support arms as shown into holes on main section. Bend upwards.

Tighten cap screws with allen key.

Ensure all fixings are fastened tightly.

