

## Wear Resistant Putty (WR-2)

**Description:** A ceramic-filled epoxy putty with a smooth, low-friction finish. Intended Use: For repairing flange faces, machine ways, valve seats and bodies, and tracing guides Product Rebuilds and protects interfacing metal surfaces features: Protects metal from bi-metallic corrosion Repairs metals and concrete Limitations: Not recommended for long term exposure to concentrated acids or to organic solvents Typical Technical data should be considered representative or typical only and should not be used for specification purposes. Physical **Properties:** 

Cured 7 days @ 75° F Adhesive Tensile Shear **Coefficient of Thermal Expansion** Color **Compresive Strength** Coverage/lb **Cured Hardness Cured Shrinkage Dielectric Constant Dielectric Strength** Flexural Strength **Functional Cure** Mix Ratio by Volume Mix Ratio by Weight **Mixed Viscosity** Modulus of Elasticity Pot Life @ 75F **Recoat Time** Solids by Volume Specific Gravity Specific Volume Temperature Resistance Thermal Conductivity

2,200 psi 32 [(in.)/(in). x °F)] x 10(-6) **Dark Grey** 9,800 psi 56 sq. in./lb. @ 1/4" 85D 0.0005 in./in. 6.3 400 volts/mil 6,500 psi 16 hrs 4:1 9.1 Putty 7.5 psi x 10(5) 45 min. 2-4 hrs 100 1.8 gm/cc 13.9 in.(3)/lb. Wet: 130°F; Dry: 250°F 1.67[(cal x cm)/(sec x cm(2) :

## **TESTS CONDUCTED**

Adhesive Tensile Shear ASTM D 1002 Cure Shrinkage ASTM D 2566 Dielectric Strength, volts/mil ASTM D 149 Dielectric Constant ASTM D 150 Modulus of Elasticity ASTM D 638 Compressive Strength ASTM D 695 Cured Hardness Shore D ASTM D 2240 Coef. of Thermal Expansion ASTM D 696 Flexural Strength ASTM D 790 Thermal Conductivity ASTM C 177

Surface Preparation: 1. Thoroughly clean the surface with Devcon® Cleaner Blend 300 to remove all oil, grease and dirt.

2. Grit blast surface area with 8-40 mesh grit, or grind with a coarse wheel or abrasive disc pad, to create increased surface area for better adhesion (Caution: An abrasive disc pad can only be used provided white metal is revealed). Desired profile is 3-5mil, including defined edges (do not "feather-edge" epoxy).

Note: For metals exposed to sea water or other salt solution, grit-blast and high-pressure-water-blast the area, then leave overnight to allow any salts in the metal to "sweat" to the surface. Repeat blasting to "sweat out" all soluble salts. Perform chloride contamination test to determine soluble salt content (should be no more than 40ppm).

3. Clean surface again with Devcon® Cleaner Blend 300 to remove all traces of oil, grease, dust or other foreign substances from the grit blasting.

4. Repair surface as soon as possible to eliminate any changes or surface contaminants.

WORKING CONDITIONS: Ideal application temperature is 55°F to 90°F. In cold working conditions, directly heat repair area to100-110°F prior to applying epoxy and maintain at this temperature during product cure to dry off any moisture, contamination or solvents, as well as to achieve maximum performance properties.

Mixing	It is strongly recommended t	hat full units be mixed, a	s ratios are pre-measured	
Instructions:	<ol> <li>Add hardener to resin.</li> <li>Mix thoroughly with screwdriver or similar tool (continuously scrape material away from sides and bottom of container) until a uniform, streak-free consistency is obtained.</li> </ol>			
	INTERMEDIATE SIZES (1,2,3 lb. units): Place resin and hardener on a flat, disposable surface such as cardboard plywood or plastic sheet. Use a trowel or wide-blade tool to mix the material as in Step 2 above.			
	LARGE SIZES: (25 lb., 30 lb., 50 lb. buckets): Use a T-shaped mixing paddle or a propeller-type Jiffy Mixer Model ES or an electric drill. Thoroughly fold putty by vigorously moving paddle/propeller up and down until a homogenous mix of res and hardener is attained.			
Application Instructions:	Spread mixed material on repair area and work firmly into substrate to ensure maximum surface contact. Wear Resistant Putty (WR-2) fully cures in 16 hours, at which time it can be machined, drilled, or painted.			
	FOR BRIDGING LARGE GAPS OR HOLES Place fiberglass sheet, expanded metal, or mechanical fasteners between repair area and Wear Resistant Putty (WR-2) prior to application.			
	FOR VERTICAL SURFACE APPLICATIONS Wear Resistant Putty (WR-2) can be troweled up to 1/4" thick without sagging.			
	FOR MAXIMUM PHYSICAL PROPERTIES Cure at room temperature for 2.5 hours, then heat cure for 4 hours @ 200°F.			
	FOR ± 70°F APPLICATIONS Applying epoxy at temperatures below 70°F lengthens functional cure and pot life times. Conversely, applying above 70°F shortens functional cure and pot life.			
Storage:	Store at room temperature, 70 °F.			
Compliances:	N/A			
Chemical Resistance:			np. cure (30 days immersion) @ 75°F)	
nesistance.	1,1,1-Trichloroethane	Very good	Phosphoric 10%	Very good
	Ammonia	Very good	Potassium Hydroxide 20%	Very good
	Cutting Oil	Very good	Sodium Chloride Brine	Very good
	Gasoline (Unleaded)	Very good	Sodium Hydroxide 10%	Very good
	Hydrochloric 10%	Very good	Sulfuric 10%	Very good
	Kerosene	Very good	Sulfuric 50%	Poor
	Methyl Ethyl Ketone	Poor	Trisodium Phosphate	Very good
	Methylene Chloride	Poor	Xylene	Fair
Precautions:	Please refer to the appropriate safety data sheet (SDS) prior to using this product.			
	For technical assistance, please call 1-855-489-7262			
	FOR INDUSTRIAL USE ONI	Y		
Warranty:	ITW Performance Polymers will replace any material found to be defective. Because the storage, handling and application of this material is beyond our control, we can accept no liability for the results obtained.			
Disclaimer:	All information on this data sheet is based on laboratory testing and is not intended for design purposes. ITW			
	Performance Polymers makes no representations or warranties of any kind concerning this data.			
Order	11410 1 lb. kit			
Information:	11420 3 lb.			
	I			