
### JY-18B Timer Board

Input Voltage	DC+12V			
Standby	Display shows:00:00, rely: Normal Open (NO)			
Accumulated time	Yes, add time if receive signals again when time is running			
Device input	2 set USB connector			
Output	2 set USB connector			
How it works				
Mode 1	Time runs down after receive signals-> Display shows remaining time and supply			
	power to device-> it cuts off power after time runs out			
Mode 2	Display shows remaining time after receive signals-> push button start-> time runs			
(Connect a button)	down and supply power to device-> it cuts off power after time runs out			
Pause	Pause Push button pause: it cuts off power when pause, display shows remaining time.			
(connect a button)	Re-supply power after push button pause again			
Price/time setting	Please reference to page 2			
Operating Mode	Please reference to page 3			

# Connection and Position



#### JY-18B Timer Board



1: Display

2: YELLOW: DC12V, WHITE: input signal, BLACK: GND

3: AC jack-5.5mm\*2.1mm

4:1 set for USB input and output-control your USB device


5:1 set for USB input and output-control your USB device

6: START for operated mode 01:02

7: Pause

8-11: Button S2, S1, S3, and S4

# Setting



DISPLAY

**Max Time:99:59 Display: 99:59** 

A: 2 digit: either HOUR or MINUTE

**B**: 2 digits: either MINUTE or SECOND

Please following page 3 to adjust Time type.

Please follow CODE ON DISPLAY and use button "S1" and "S2" to set up number

#### INPUT SIGNAL QUANTITY AND TIME

- 1. Please press button "S4". "B" flashes. Please set up INPUT SIGNAL QUANTITY to active device (01-50).
- Please press button "S4", "A" flashes. Please set up TIME (01-99). 2.
- Please press button "S4", "B" flashes. Please set up TIME (01-99). 3.
- Please press button "S4" 4 TIMES. 4.
- Please set up TIME for Warning Sound. 5.
- Please press button "S4" to finish. 6.
- **GIVEN TIME:** Add time by free if input signals reach SETTING RATE during time is running.

**Example Setting**: input signal to active device: 01, input signals for given time: 03 give time: 02:10 Add time "02:10" free if receive "3 signals" during time is running.

- Please press button "S4" 4 TIMES. "B" flashes. Please set up RATE OF INPUT SIGNAL QUANTITY.
- Please press button "S4", "A" flashes. Please set up GIVEN TIME.
- Please press button "S4", "B" flashes. Please set up GIVEN TIME.
- Please press button "S4" to finish.

## **JY-18B Timer Board**

#### Mode Setting

Please follow table to set up operating function:

- 1. Please hold on button "S1" and "S2" simultaneously for 3 seconds to get into MODE SETTING.
- 2. Please use button "S1" and button "S2" to set up number for **CODE**
- 3. Please press button "S4" to switch to next code

Function	<b>Code on Display</b>		Description	
	A	В	Description	
Running Time	01	<u>01</u>	Time runs down without pressing button	
		02	Time runs down by pressing button	
Time Type	02	<u>03</u>	MINUTE: SECOND	
		04	HOUR: MINUTE	
Memory	03	05	Yes: Remaining time keep running after power off and on	
		<u>06</u>	No: Standby power off and on	
Back to standby	04	1-30	user has no action after push buttons or receive signals in	
			setting time	
Default: 01-03: Bold and base line. 04: not use the function.				

## Size and Connection Example

