


Deroma

Deroma

Product Structure



Warranty

Warranty is applied upon manufacturing defect only. Warranty does not cover defects and malfunction due to essential oil, human misuse and abnormal voltage or in-coming power supply.

Please register your warranty at below QR Code



Instructions of Essential Oil & Sanitizer

1. Deroma M977 is designed mainly for the function of humidify your environment. The main function of humidifier is to diffuse water mist.
2. Diffuse water mist will help to reduce the temperature (1-2celcius) and help to avoid dry environment.
3. **Essential Oil and Alcohol Base Sanitizer is STRICTLY not allowed** to mix into the water tank and also motor base area, except aroma oil space.
4. Mixture of **essential oil and alcohol base sanitizer** into the product will void the warranty.

New Formulated Aroma for Deroma Humidifier

1. Deroma is new formulated water based fragrance with essential oil that is safe for Deroma Humidifier machine.
2. If user wishes Deroma Humidifier can help to diffuse good smell mist for more comfortable environment, **STRICTLY** only use Deroma Water Based Essential Oil that has been tested safe for Deroma Humidifier.
3. Mixture of other essential into water tank will void the warranty as Deroma only will be distributed by selected dealer. Please provide the proof of purchase, if claimed humidifier is damaged due to Deroma essential oil.

Gentle Reminder

1. Do not leave or soak the essential oil, sanitizer or any liquid in the humidifier or motor part overnight or when not in use in a period of time.
2. Please keep the humidifier water tank and motor part dry when not in use for a period of time to prevent any damage on the parts.

Deroma


Deroma

Deroma
Air Humidifier
With UV Light

M977

Instruction Manual

Innovate With Science & Technology
Succeed With Excellent Quality



Manufactured & Distributed by:

Deroma Holding Sdn. Bhd.

Address: K1-9, Jalan 3, Taman Seri Merdeka,
68000 Ampang, Selangor.

☎ Call: +603-4288 5351

☎ +6013-556 1199

Website: www.deerma.com.my

E-mail: deromamy@gmail.com

Thanks for choosing our product
Read the instruction carefully before use

Products Specification

Product Name: Air Humidifier
 Product Model: M977
 Capacity: 9.0L
 Power: 26W
 Voltage: 220-240V~50/60Hz
 Mist: 300mL/H
 Dimension: Approx. 216*216*699mm
 Weight: Approx. 2.2kg

Packing List

Parts Name	Quantity
Air Humidifier	1
Instruction Manual	1
Warranty Card	1

Failure Analysis and Solutions

Mist knob is switch on, no wind and mist?

Cause: Power is not connected or there is a problem on the power.

Solution: Reconnect power supply. If still unable to function, kindly contact our customer service.

The light is on, but there is no wind and no mist?

Cause: Lack of water

Solution: Fill water in water tank.

Mist volume is low

Cause: Atomizer plate is not clean or water is not pure enough.

Solution: Clean the atomizer plate and replace with clean water.


Mist leak from mist nozzle surrounding

Cause: There are gap between mist nozzle with water tank.

Solution: Soak the mist nozzle in water and replace back.

Product Instructions

1. Remove the humidifier from box and place on a flat surface. Remove the water tank cover and fill with water (do not exceed the max. water level), place back the water tank cover and connect the cable plug.



2. Press On/Off button, the machine will enter default mode; the mist will be at highest level. UV light on; water tank with blue light; the screen showing current humidity level; other function at standby mode.

3. Timer: Press “Timer” button, the screen will show the timer digit (adjust starting from 1 hour). Each press will add 1 hour, able to set until 14 hours, then enter timer mode. When the operating time reaches the time set, the machine will stop operating (Note: the timer digit is by countdown)

4. UV Sterilization: After on the humidifier, the machine will enter the UV sterilization mode automatically. Press UV sterilization button to off the UV mode.

5. Sleep: Press “Sleep” button, the screen, digit and water tank light will off after 5 seconds, but other functions are operating as normal. Press any button to dismiss sleep mode.

6. Humidity: Press “Humidity” button to adjust humidity level. The starting humidity is 55%RH. Press one time to add 5% RH. (The humidity level setting is from 30-95%RH). After set to the preferred humidity level, the digit will blink 3 seconds and enter the humidity mode. The humidity digit shown is current humidity level. When the humidity reaches the set level, the mist function will stop working. When the humidity is lower 5%RH than the setting, the misting function will start working.

Product Instructions

7. Mist: The default mode as highest level mist “■■■■■”, press one time to set middle mist level “■■■■□”, press another time for lowest level “■■■□□”.

8. Water tank light: The function as default mode, the light will automatically off after the machine is off.

9. Cover and main motor auto cut-off when lift up: The machine will auto cut-off operation when the cover and main motor is lift up.


10. Water shortage: When the water tank is lack of water, the machine will stop operate, LED panel will show red color at the water shortage icon. Refill water and restart the machine.

Cleaning And Maintenance

Add detergent powder (for humidifier) with clean water and soak as per detergent instructions. Use a brush to scrub gently the atomizer and rinse with clean water and leave it dry. Recommend to clean humidifier regularly, once a week or every 2-3 days if using essential oil or sanitizer.


Water Tank Cleaning

Remove the main motor, clean the water tank and place back the main motor.



Upper Component Cleaning

Remove cover and middle board, clean the water tank and place back all accessories.



Precautions

1. The power supply voltage must be consistent with the rated power of this product.
2. This appliances is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Please use the product at normal room temperature (5° C~40° C), humidity: <80%RH.
4. Please put and use the product on a flat surface.
5. Please do not use the humidifier directly on a wooden floor, to prevent the floor from damage.
6. Please put the humidifier 2 meter away from furniture & electronic devices, to prevent from wet.
7. Please prevent the humidifier from heat and direct sunlight.
8. Do not insert water higher than 40° C into the water tank to prevent product from damage.
9. Do not allow water to flow from the air outlet to the body. If there is, wipe it with dry cloth to prevent damage to the machine.
10. If there is any abnormal sound or smell, turn off the humidifier immediately.
11. Please do not insert any metal, chemical or detergent to the water tank or base.
12. Turn off the power supply and unplug before pouring the water from the water tank.
13. Do remember to off the power supply and unplug if there is need to adjust, clean and add water. Do not move the product when it is working.
14. Strictly not allowed to insert water into the mist nozzle and air outlet.
15. When cleaning, prevent the product from water.
16. Do not simply disassemble the product.
17. To avoid growth of bacteria, do clean the humidifier regularly.
18. This humidifier is for household use only.