YOCHIYOCHI

CHILD SAFETY HARNESS



3-in-1 CHILD SAFETY HARNESS

• Walking harness • Portable high chair • Cart safety strap **Recommended age:** 6 mos. / when your child can sit up unaided to 5 yrs.

(max. chest/tummy size: 25.5 inches)

YOCHYOCH Walking Harness

RECOMMENDED AGE:

When your child starts walking to 5yrs. (max. chest/tummy size 25.5")



1. Fold the leg openings into the harness, and strap around your child, ensuring that it is not too tight and your child can breathe comfortably, but not so loose that it slides down under the waist. The Velcro opening should be on the back.



2. Adjust the strap to your desired length, and voila!

Portable High Chair

RECOMMENDED AGE:

6 mos. / when your child can sit up unaided to 5 yrs. (max. chest/tummy size 25.5")



1. Pass your child's legs through the leg openings, as shown.



2. Fasten the Velcro strap behind your child's back, ensuring it is not too tight and your child can breathe comfortably.



3. Loop the strap around the back of the chair and adjust the strap as necessary to secure your child to the chair.*

*Fits most chairs; cannot be used on stools or backless chairs

Cart Safety Strap

RECOMMENDED AGE:

6 mos. / when your child can sit up unaided to 5 yrs. (max. chest/tummy size 25.5")



1. Pass your child's legs through the leg openings, as shown.



2. Fasten the Velcro strap behind your child's back, ensuring it is not too tight and your child can breathe comfortably.



3. Loop the strap through the bars behind baby and adjust the strap as necessary to secure your child to the



Improper use of the Yochi Yochi may cause serious injuries or death.

- Do not leave your child unattended.
- Ensure the Velcro strap is fastened securely at all times while in use.
- The Yochi Yochi cannot be used as a car seat.
- When used as a walking harness, always keep an eye on your child.
- · Avoid use near fire.
- Before use, please examine for any damage, breakage or fraying.
- Young children can become entangled and strangle on cords and loops. Always keep an eye on your child and use precaution at all times to avoid entanglement and strangulation.

CARE INSTRUCTIONS:

- Spots can be wiped clean.
- For tougher spots, close the Velcro strap before placing in the washing machine.
- Machine wash gently in laundry net to avoid damage to buckles.
- Do not iron or dry clean.
- Lay flat to dry.



